

64 DIN 41612 Connector List

From: 82E322 Patchable Stereo VCAs Mother board

To: 82E321 Ribbon Interface card

No	Row A	No	Row C
1	Fader 1 Computer Return	1	Cut Switch 1
2	Fader 2 Computer Return	2	Cut Lamp 1
3	Fader 3 Computer Return	3	AFL Switch 1
4	Fader 4 Computer Return	4	Cut Switch 2
5	OV	5	Cut Lamp 2
6	Fader 1 Computer Send	6	AFL Switch 2
7	Fader 2 Computer Send	7	Cut Switch 3
8	Fader 3 Computer Send	8	Cut Lamp 3
9	Fader 4 Computer Send	9	AFL Switch 3
10	OV	10	Cut Switch 4
11	Fader 1 Wiper	11	Cut Lamp 4
12	Fader 1 +5V	12	AFL Switch 4
13	Fader 1 Thumbwheel	13	
14	Fader 1 OV (M)	14	
15	Fader 2 Wiper	15	+18V
16	Fader 2 +5V	16	+18V
17	Fader 2 Thumbwheel	17	OV L
18	Fader 2 OV (M)	18	OV M
19	Fader 3 Wiper	19	OV R
20	Fader 3 +5V	20	-18V
21	Fader 3 Thumbwheel	21	-18V
22	Fader 3 OV (M)	22	
23	Fader 4 Wiper	23	
24	Fader 4 +5V	24	
25	Fader 4 Thumbwheel	25	AFL Mix Bus L
26	Fader 4 OV (M)	26	OV
27		27	AFL Mix Bus R
28		28	OV
29		29	AFL Mix Bus O/P L
30		30	OV
31		31	AFL Mix Bus O/P R
32		32	OV

PATCHABLE VCAs: EUROCARD PINOUTS
23.Dec.1987

S12E	64 DIN 41612 CONNECTOR	CIRCUIT
1	11A	Fader 1 Wiper
2	12A	Fader 1 +5V
3	13A	Fader 1 Thumbwheel
4	14A	Fader 1 0V
5	15A	Fader 2 Wiper
6	16A	Fader 2 +5V
7	17A	Fader 2 Thumbwheel
8	18A	Fader 2 0V
9		Not used
10		Not used
11		Not used
12		Not used
13	19A	Fader 3 Wiper
14	20A	Fader 3 +5V
15	21A	Fader 3 Thumbwheel
16	22A	Fader 3 0V
17	23A	Fader 4 Wiper
18	24A	Fader 4 +5V
19	25A	Fader 4 Thumbwheel
20	26A	Fader 4 0V

S16E	64 DIN 41612 CONNECTOR	CIRCUIT
1	1A	Fader 1 Computer Return
2	2A	Fader 2 Computer Return
3	3A	Fader 3 Computer Return
4	4A	Fader 4 Computer Return
5		Not used
6		Not used
7		Not used
8		Not used
9		Not used
10	5A	0V
11	6A	Fader 1 Computer Send
12	7A	Fader 2 Computer Send
13	8A	Fader 3 Computer Send
14	9A	Fader 4 Computer Send
15		Not used
16		Not used
17		Not used
18		Not used
19		Not used
20	10A	0V

S93E	64 DIN 41612 CONNECTOR	CIRCUIT
1	1C	Cut Switch 1
2	2C	Cut Lamp 1
3	3C	AFL Switch 1
4	4C	Cut Switch 2
5	5C	Cut Lamp 2
6	6C	AFL Switch 2
7	7C	Cut Switch 3
8	8C	Cut Lamp 3
9	9C	AFL Switch 3
10	10C	Cut Switch 4
11	11C	Cut Lamp 4
12	12C	AFL Switch 4
13		
14		
15		
16		
17		
18		
19		
20		

